

Lip Gloss – "Vibrant Very Peri Lip Gloss" Ref: CC/3306/US

Color Cosmetics

Product Name	INCI Name	%W/W	Supplier
A		100.00	
Versagel ME 750	Hydrogenated Polyisobutene (and) Ethylene/Propylene/Styrene Copolymer (and) Butylene/Ethylene/Styrene Copolymer	82.00	www.calumetspecialty.com
Dermol DID	Diisopropyl Dimer Dilinoleate	8.00	www.alzo.com
Permethyl 104A	Polyisobutene	8.00	www.presperse.com
D&C Red 28 AI Lake (333% in castor oil)	D&C Red 28 AI Lake	0.60	www.sunchemical.com
FD&C Blue 1 (45% in castor oil)	FD&C Blue 1 Al Lake	0.40	www.sunchemical.com
В			
Mirage Silver	Calcium Sodium Borosilicate (and) Titanium Dioxide	1.00	www.eckart.net
	Flavor	qs	
	preservative	qs	

Procedure:

- 1. Mix phase A
- 2. Add phase B to phase A and mix until uniform
- 3. Add phase C and pour into a lip gloss container

⇒ SYNCRYSTAL Silver provides a dewy, glossy sheen to a slightly tinted Very Peri Color.



Customer Support

ECKART GmbH info.eckart@altana.com

ECKART America Corporation info.eckart.cosmetics@altana.com

ECKART Asia Limited info.eckart.asia@altana.com

This document does not constitute a legally binding obligation of Eckart. While the information contained herein and our technical advice – whether verbal, in writing or by way of trials – are given in good faith, it is provided for your guidance only. We recommend testing our products as to their suitability for your envisaged purpose prior to use. Furthermore, you are responsible for observing all laws and regulations relevant to any products mentioned herein and the products' application. No warranties of any kind, either express or implied, including warranties of merchantability or fitness for a particular purpose, are made regarding any products mentioned herein and data or information set forth, or that such products, data or information may be used without infringing intellectual property rights of third parties.

